



ANOTO PENDOCUMENTS PRO

INSTALLATION GUIDE

PC REQUIREMENTS


- Windows® XP SP2 or Windows Vista®
- 1 GHz 32-bit (x86) processor
- 512 MB of system memory
- 1 GB hard drive
- PDF viewing software such as Adobe® Reader

ANOTO PENDOCUMENTS PRO

Anoto penDocuments Pro digitally captures your handwriting as you write. You can save, store and send documents immediately.

For instructions on how to use the Anoto Digital Pen, refer to the Anoto Digital Pen DP-201 User's Guide enclosed in the Anoto penDocuments Pro kit. For instructions on operating Anoto penDocuments Pro, refer to the User's Guide, which is part of the Anoto penDocuments Pro application and can also be found at <http://www.anoto.com/pendocumentspro>.

INSTALLATION

1. Do not connect the digital pen to your computer until **after** you have installed Anoto penDocuments Pro. Connecting the digital pen too early will cause Windows to install a default driver which will not support the digital pen. Go to the Anoto penDocuments Pro web site <http://www.anoto.com/pendocumentspro>, and click on the icon labeled "Download/Installation" then click "Download here". 
2. The installation of Anoto penDocuments Pro starts. Follow the instructions on the screen; the software installer will guide you through the installation process. When the installation is finished, reboot your computer.
3. The first time you run Anoto penDocuments Pro you are asked to register both you as a user and to register the pen. The instructions on the screen guide you through the process to register by entering Pen ID and the Product License Key (PLK). Make sure your computer is online before attempting to register. You will find the pen ID on the pen or on a sticker that came with the pen.
4. The first time you run Anoto penDocuments Pro, you are also asked to define a physical printer as the Anoto Print printer. The instructions on the screen guide you through the process.

MORE INFORMATION ABOUT ANOTO PENDOCUMENTS PRO

At <http://www.anoto.com/pendocumentspro> you will find more information about Anoto penDocuments Pro:



Using Anoto penDocuments Pro

Explore what Anoto penDocuments Pro can do and how it does it



Download / Installation

Get up and running with your copy of Anoto penDocuments Pro



Application Store

Find free trials and downloads of connectors and applications



Development Zone

Start developing your own digital pen and paper based applications



Feedback and Support

Send us your comments so that we can make Anoto penDocuments Pro better

HOW TO CHANGE THE INK CARTRIDGE IN THE PEN

To exchange the ink cartridge follow the outlined steps below

- 1) remove the pen cap from the pen
- 2) hold the pen cap in one hand and the pen in the other.
- 3) insert the tip of the ink cartridge into the small hole in the pen cap
- 4) gently turn the pen to a slight angle in order to create some pressure
- 5) pull the pen away from the cap, the cartridge will slide out of the pen
- 6) gently push the new ink cartridge into the pen by hand



INTERNET AND SERVER ACCESS

Anoto penDocuments Pro requires Internet access during its operation; first of all during registration of license keys and user information, and then occasionally during regular operation for the purpose of administration of the Anoto pattern printed on the documents. The access is normally done in the background without any need for manual intervention.

However, Internet security software and firewalls may issue warnings and/or block Anoto penDocuments Pro when it tries to access Internet. If this happens and you are not sure of how to resolve the situation, please contact your computer or network administrator. If the application is not allowed to access internet, parts of it will eventually stop working.

When accessing Internet, the application communicates with servers hosted by Anoto and/or its business partners. Anoto is dedicated to maintain server operation for smooth and uninterrupted use of Anoto penDocuments Pro. Anoto penDocuments Pro is further designed to be fault tolerant, allowing continued operation also if a server is unavailable for some time, for example due to maintenance work. However, if Anoto penDocuments Pro is used intensively, you might experience temporary functional interruptions if a server does not respond. In such case you have to wait and try again at later time. If the situation persists and you have verified that it does not depend on your own Internet connection, then please contact the supplier of Anoto penDocuments Pro for support.

Anoto can regretfully not guarantee uninterrupted operation of the servers at all times.

PRIVACY STATEMENT

When starting Anoto penDocuments Pro, you will be requested to enter your name, the name of the company or other entity you represent, and your e-mail address. This and information about the installation environment will be sent and stored on Anoto's and/or its licensor's servers for the sole purpose of providing you with information about Anoto penDocuments Pro-related updates and support.

Anoto respects your privacy. None of the submitted information will be used for any other purpose than as stated above. The information will in no event be sold, traded or otherwise shared by Anoto with any third party, except to Anoto's licensors and other associated companies who have a need to access the information for said purposes. The information may be transmitted to countries not included in the European Union or being a part of the EEA.

Anoto complies with national data protection laws that control the use and the collection of personal data. You are entitled to receive further information relating to the processing of your personal data, and to have any detected incorrectness corrected. You may at any time request that your personal data will be removed from Anoto's and associated companies' records. Contact Anoto for information, correction and/or removal of your personal data.